


便携式条形音箱

使用说明书 MZ-612



安全须知

- 请仔细阅读本说明书并妥善保管以备将来参考。
- 请将本产品调至合适音量,避免对您的听力造成损害。
- 为减少火灾和触电危险,请勿让本产品淋雨或受潮。
- 请勿将本产品放置在热源附近,避免靠近散热器,火炉和其它会发热的设备。
- 请勿堵塞本产品的开口处,勿将物体塞入本产品的通风口或槽隙中。
- 请勿丢弃,避免因跌落造成本产品损坏。
- 如果电池更换不当会有爆炸危险,只能用同样类型或等效类型的电池来更换。
- 无论设备因何种原因损坏,都必须及时请专业维修人员修理,擅自拆卸将使保修失效。


包装内容

- 无线音箱 X1
- USB数据线 X1
- AUX线 X1
- 说明书 X1

充电提示

- 低电量时,音箱会发出低电报警提示语音,1分钟内检测到3次自动关机。
- 充电时,红灯常亮,充满红灯熄灭。

产品概述



M “INPUT”键

- 开机状态下短按“INPUT”功能,循环短按进行“BT”“USB”“AUX”“FM”切换
- 长按10秒复位功能,复位后关机

◀ “PREV”键

- 在“BT”“USB”状态下短按为播放上一首
- 在“FM”状态下播放上一电台

⏸ “PLAY/PAUSE”键

- 在“BT”“USB”“AUX”状态下短按播放/暂停
- 在“FM”状态下长按3秒进行自动寻台并自动记忆,短按暂停搜台
- 在“BT”状态下双击进入音箱TWS配对模式(并有相应的提示语音),长按3秒蓝牙强制断开连接

💡 “RGB LED”键

- 循环短按可控制RGB灯的状态,也可开关RGB灯
- 工作模式参见RGB灯工作模式

▶ “NEXT”键

- 在“BT”“USB”状态下短按为播放下一首
- 在“FM”状态下播放下一电台

① 充电接口:DC 5V 1A

- 插入Type-C接口自动充电,充电时红灯常亮,充满红灯熄灭

② AUX输入接口

- 插入AUX线自动转到外接音乐播放模式,并有相应的提示语音

③ USB接口

- 插入U盘,并有相应的提示语音,并进入USB工作状态

④ “Power ON/OFF VOL+/-”旋钮


- 长按3秒开机/关机,并有相应的提示语音和LED灯
- 旋转旋钮:可以实现VOL+/-功能,并有相应的提示语音(最大音量)和LED灯

工作状态LED灯

- 蓝牙指示灯:配对前慢闪,配对完成后常亮,播放常亮
- USB指示灯:插入U盘后自动播放,播放LED灯常亮
- AUX指示灯:插入AUX后自动播放,播放LED灯常亮
- 编码器指示灯:长按3秒“Power ON/OFF VOL+/-”旋钮开机,LED灯慢闪,马上进入蓝牙配对模式,此时加减音量编码器时,最大音量时有提示音
- RGB灯条:长按3秒“Power ON/OFF VOL+/-”旋钮开机,进入RGB灯亮灯多彩渐变模式,此时通过短按RGB灯键“💡”来控制RGB灯工作模式切换与开关

RGB灯工作模式

- 短按RGB灯键“💡”,RGB灯颜色显示按以下顺序排列:
RGB灯亮灯多彩渐变模式
RGB灯亮灯多彩跑马模式
RGB灯亮灯单色跑马模式
RGB灯亮灯呼吸渐变模式
关灯状态
- 在“FM”状态下:按下RGB灯键“💡”无作用,RGB灯为关闭状态



蓝牙配对

- 长按3秒“Power ON/OFF VOL+/-”旋钮开机,LED灯慢闪,马上进入蓝牙配对模式,有相应的提示语音,音箱进入与手机蓝牙搜索配对状态,默认音量为80%。
- 打开手机或其他蓝牙设备上的蓝牙功能,然后搜索名为“BT-SOUNDBAR”的音箱,与音箱连接。
- 配对成功后,LED灯常亮,有相应的提示语音。
- 如果设备蓝牙功能开启,打开音箱后,音箱将自动连接到最后一个配对设备。
- 如何将音箱与新设备连接:
音箱与蓝牙设备连接时,长按3秒PLAY/PAUSE键“⏸”切断当前连接并进入配对状态。此时蓝色指示灯将慢闪,音箱就可以与新设备连接。
注意:所有状态下,若无音乐播放时,10分钟后自动关机。

TWS

- 打开两台音箱,双击其中一台音箱PLAY/PAUSE键“⏸”进入TWS相互连接状态,并有相应的提示语音,此时蓝牙指示灯慢闪为主机模式进行TWS组队,另一台音箱组队成功有相应的提示语音并且蓝牙指示灯常亮为从机模式,然后再将另一台主机音箱与蓝牙设备连接播放音乐,下次开启音箱将会自动连接。
注意:已配对成功的两个音箱,再次短按两次主音箱PLAY/PAUSE键“⏸”可断开TWS连接。

FM电台

- 短按INPUT键“M”转换到“FM”状态,并有相应的提示语音。
- 在“FM”状态下,长按3秒PLAY/PAUSE键“⏸”进行自动寻台并自动记忆,短按PLAY/PAUSE键“⏸”暂停搜台。

AUX模式

- 插入AUX线自动转到外接音乐播放模式,并有相应的提示语音后音箱自动播放,LED灯常亮。
- 在AUX状态下,短按PLAY/PAUSE键“⏸”为播放,LED灯常亮,再短按PLAY/PAUSE键“⏸”为暂停,LED灯慢闪一次。

产品参数

- 工作时长:10hr(50%音量)
- 待机时长:≥300hr
- 蓝牙范围:≤10m
- 频率响应:40Hz-20KHz
- 蓝牙版本:V5.3
- 电池容量:2000mAh
- 充电时长:4hr
- 工作电压:DC 5V 1A
- 峰值功率:20W
- 充电方式:Type-C
- 产品尺寸:405*73*80mm

保修卡

产品型号	购买日期
经销商	用户姓名
联系电话	电子邮件
用户地址	


保修记录

用户姓名	故障描述	维修日期	维修员签字



Portable Soundbar Speaker

User manual MZ-612



Safety precautions

- Please read this user manual carefully and keep it properly for future reference.
- Please adjust this product to a suitable volume to avoid damaging your hearing.
- To reduce the risk of fire and electric shock, do not expose this product to rain or moisture.
- Do not place this product near a heat source, such as a radiator, fireplace, or other device that produces heat.
- Do not block the openings of this product and do not insert objects into the ventilation or slot openings.
- Do not dispose of this product and avoid dropping it to prevent damage.
- If the battery is replaced incorrectly, there is a risk of explosion. Only use the same type or an equivalent type of battery for replacement.
- Regardless of the reason for the device damage, it must be repaired by a professional technician in a timely manner. Unauthorized disassembly will void the warranty.


Package contents

- Wireless Speaker X1
- USB data cable X1
- AUX cable X1
- User manual X1

Charging tips

- When the battery is low, the speaker will emit a low battery alert voice prompt. If the battery level remains low and the speaker detects three low battery alerts within one minute, it will automatically power off.
- When charging, the red light will remain on, and when fully charged, the red light will turn off.

Product overview



INPUT key

- Short press the "Input" function when turned on, cycle short press to switch between "BT", "USB", "AUX", and "FM"
- Long press and hold for 10 seconds to reset the function, and then shut down after resetting

PREV key

- Short press to play the previous song in "BT" or "USB" mode
- Playing the previous radio station in "FM" mode

NEXT key

- Short press to play the next song in "BT" or "USB" mode
- Play the next radio station in "FM" mode

RGB LED key

- Cyclic short press can control the status of the RGB light and also switch the RGB light on and off
 - Working mode refer to RGB light working mode
- ### PLAY/PAUSE key
- Short press to play/pause in the "BT", "USB", and "AUX" states
 - Press and hold for 3 seconds in the "FM" mode to automatically search for channels and memorize them.
 - In the "BT" state, double-click to enter the speaker TWS pairing mode (with corresponding prompt voice), and press and hold Bluetooth for 3 seconds to force disconnection

Charging interface: DC 5V 1A

- Insert Type-C interface for automatic charging, with a red light constantly on during charging and a red light off when fully charged

AUX input interface

- Insert AUX cable and automatically switch to external music playback mode with corresponding prompt voice

USB interface

- Insert the USB drive with corresponding prompt voice and enter the USB working state

Power ON/OFF VOL+/- knob

- Long press for 3 seconds to turn on/off, with corresponding prompt voice and LED lights
- Rotary knob: can achieve VOL+/- function, with corresponding prompt voice (maximum volume) and LED lights


Working status LED light

- Bluetooth indicator light: Flashes slowly before pairing, remains on after pairing, and remains on during playback
- USB indicator light: Automatically play after inserting the USB drive, and the play LED light remains on
- AUX indicator light: Automatically play after inserting AUX, and the play LED light remains on
- Encoder indicator light: Press and hold the "Power ON/OFF VOL+/-" knob for 3 seconds to turn on the device. The LED light will slowly flash and immediately enter Bluetooth pairing mode. At this time, when the volume encoder is increased or decreased, there will be a prompt sound when the maximum volume is reached
- RGB light bar: Press and hold the "Power ON/OFF VOL+/-" knob for 3 seconds to turn on the RGB light bar. Enter the RGB light on colorful gradient mode. At this time, press and hold the RGB light key " " briefly to control the RGB light working mode switch and switch

RGB light working mode

- Short press the RGB light key " ", and the RGB light colors will be displayed in the following order:
 RGB light on colorful gradient mode
 RGB light on colorful running mode
 RGB light on monochrome running mode
 RGB light on breathing gradient mode
 Off light status

- In the "FM" state: Pressing the RGB light key " " has no effect, and the RGB light is turned off



Bluetooth pairing

- Press and hold the "Power ON/OFF VOL+/-" knob for 3 seconds to turn on the phone. The LED light will slowly flash and immediately enter Bluetooth pairing mode. There will be a corresponding prompt voice, and the speaker will enter Bluetooth search pairing mode with the phone. The default volume is 80%.
- Turn on the Bluetooth function on your phone or other Bluetooth device, and then search for a speaker named "BT SOUNDBAR" to connect to it.
- After successful pairing, the LED light remains on and there is a corresponding prompt voice.
- If the Bluetooth function of the device is enabled, the speaker will automatically connect to the last paired device when turned on.
- How to connect the speaker to a new device: When connecting the speaker to a Bluetooth device, press and hold the PLAY/PAUSE key " " for 3 seconds to disconnect the current connection and enter pairing mode. At this point, the blue indicator light will slowly flash, and the speaker can be connected to the new device.

Attention: In all states, if there is no music playing, it will automatically shut down after 10 minutes.

TWS

- Open two speakers, double-click the PLAY/PAUSE key " " on one of the speakers to enter the TWS mutual connection state, and there is a corresponding prompt voice. At this time, the Bluetooth indicator light slowly flashes to the host mode for TWS teaming, and the other speaker successfully teamed up has a corresponding prompt voice and the Bluetooth indicator light is always on in the slave mode. Then, connect the other host speaker to the Bluetooth device to play music, and the next time the speaker is turned on, it will automatically connect.

FM radio

- Short press the Input key " " to switch to the "FM" state, and there will be corresponding prompt voice.
- In the "FM" state, press and hold the PLAY/PAUSE key " " for 3 seconds to automatically search for channels and memorize them. Short press the PLAY/PAUSE key " " to pause the search.

AUX mode

- When you insert an AUX cable, the speaker will automatically switch to external music playback mode, and after a corresponding prompt voice, the speaker will start playing music automatically, while the LED light will remain on.
- In AUX mode, a short press of the PLAY/PAUSE key " " will play the music and the LED light will remain on. Another short press of the PLAY/PAUSE key " " will pause the music and the LED light will slow flash once.

Product parameters

- Working time: 10 hours (50% volume)
- Standby time: ≥300 hours
- Bluetooth range: ≤10 meters
- Frequency response: 40Hz-20KHz
- Bluetooth version: V5.3
- Battery capacity: 2000mAh
- Charging time: 4 hours
- Operating voltage: DC 5V 1A
- PMPO Power: 20W
- Charging method: Type-C
- Product size: 405*73*80mm

Support Information

- Need further help, you can contact us by
- A. Service E-mail: inwa_support@innosystemtech.com
 - B. Or contact us on Amazon
 1. Go to Your Orders.
 2. Find your order in the list.
 3. Select Problem with order.
 4. Choose your topic from list displayed. Select Contact seller.

UK	REP	GOAL REACH CONSULTING LTD OFFICE 1029 3 HARDMAN STREET 10TH FLOOR, SPINNINGFIELDS MANCHESTER, UK M3 3HF
-----------	------------	--

OST_UK_20230424000006 goalservice2@hotmail.com
 We simply act as UK representative for cross-border sellers, and are not manufacturers/importers/distributors for the product, nor involved in the manufacture/import/sale of the product. Therefore, we are not responsible for any after-sales services related to the product. In case of any product quality or infringement issues, the manufacturer/importer/seller shall be solely held responsible.

EU	REP	SUCCESS COURIER SL CALLE RIO TORMES NUM.1, PLANTA 1, DERECHA, OFICINA 3, Fuenlabrada, Madrid,28947 Spain
-----------	------------	---

OST_EU_20230424000022 successservice2@hotmail.com
 We simply act as EU representative for cross-border sellers, and are not manufacturers/importers/distributors for the product, nor involved in the manufacture/import/sale of the product. Therefore, we are not responsible for any after-sales services related to the product. In case of any product quality or infringement issues, the manufacturer/importer/seller shall be solely held responsible.